

HOW TO APPLY 3D TILE STICKERS



SUITABLE SURFACES

- Smooth flat wall
- Smooth ceramic tiles
- Smooth glass tiles
- Wall panel (Acrylic)
- Wall linoleum
- Mirror
- Wallpaper

SURFACES TO AVOID

- Stucco wall
- Stone wall
- Unfinished wall (plaster)
- Unpainted plywood



TIP!

Ensure room temperature is 70°F 12 hours before & 34 hours after installation so the tiles adhere properly to the wall

Step 1



Tools for the job!

Step 2



Clean surface thoroughly ensuring all grease is removed.

Step 3



Draw a levelled line on the wall so tiles can be positioned straight.

Step 4



Tiles can be cut to size using scissors or scalpel. Draw a line on the reverse of where to cut and use a straight edge (e.g. metal rule)

Step 5



Peel away the backing paper, taking care not to touch the adhesive.

Step 6



Overlay the tiles where indicated to give a brick effect, press all the grout lines firmly.

Step 7



TIP!
If going over existing tiles, spray the surface lightly with water to aid application.

Step 8



If going around sockets, measure where to cut around.

Step 9



Use scissors to cut the shape required.



TIP!

Avoid contact with direct flame allow a minimum distance of at least 12 inches.

Step 10



Position onto the wall around the socket.

Step 11



The Finished Look!