

Tile it

How to apply 15cm Self Adhesive Wall Tiles

Before



After



*Tools for
the job*

- * Tape measure or ruler
- * Pencil
- * Cloth
- * Utility knife

STEP 1



Clean the surface thoroughly to remove any grease or dirt.

STEP 2



Peel back the backing paper to reveal the adhesive side.

STEP 3



Stick the tiles into place.

STEP 4



If you need to cut the tile...

Measure where the cut needs to be and mark on backing paper.

STEP 5



Score

STEP 6



Snap

Use over flat tiles or on painted walls. The rigid vinyl tiles can be applied over any size tile and will stop any grout lines showing through.



Mix & match to create your own look!