



How to apply Wall Pops Self Adhesive Wall Tiles



Vertical



Herringbone



*Tools for
the job*

- * Tape measure or ruler
- * Pencil
- * Spirit level

Horizontal



STEP 1



Clean the surface thoroughly to remove any grease or dirt. Wait 4 weeks before applying to newly painted surfaces (the tiles will not adhere to non-stick paint).

STEP 2



Peel back the backing paper to reveal the adhesive side. Avoid touching the adhesive as dust, dirt or oils may affect adhesion.

STEP 3



Draw a horizontal line to aid application then stick the tiles into place - Subway tiles can be stacked horizontally, vertically or in a herringbone pattern!

STEP 4



If you need to cut the tile...

Measure where the cut needs to be and mark on backing paper.

STEP 5



Score

STEP 6



Snap

Use over flat tiles or on painted walls. The rigid vinyl tiles can be applied over any size tile and will stop any grout lines showing through.



DURABLE WIPE CLEAN SURFACE!