



Heat & Glare Protection Film

Key Benefits

- * Reduces heat
- * Blocks UV rays
- * Helps protect furniture from fading
- * Ideal for home offices, south facing rooms, conservatories/sun rooms

What you need

- * Application tools included
- * Water spray
- * Lint-free cloth
- * Ruler



Top Tips

- * This film adheres to the glass using static cling technology – no adhesive
- * Apply to the inside of a clean window
- * 2 people recommended for easier application
- * Don't allow the film to crease
- * This film has a protective top layer which needs to be removed once in situ

How to apply...

STEP 1



Clean the window thoroughly to remove any dirt or dust.

STEP 2



Measure the window. Cut the film 2mm shorter in length and height than the window area (to avoid any overlap on to window seals).

STEP 3

Generously spray water all over the glass surface.

STEP 4

Remove the backing film (located on inside of the wound roll). Tape can be used if needed to prise the layers apart. Spray the exposed side of the film with plenty of water.

STEP 5

Starting at the top of the window, line the film up and let the wet side start sticking to the glass. Use your hand to guide it into position, taking care not to let the film adhere at the bottom until the top is aligned (this is where a second person is helpful).

STEP 6

Once in position, spray more water on to the surface of the film then, moving from the centre outwards, use the smoother or squeegee to push out any excess water.

STEP 7

Finally, when the film is in place and all excess water has been removed, dry with a lint-free cloth and peel away the top protective layer. Allow to dry fully.

